

Batch Export NWC

Связи	
BIM_Работа в Navisworks	https://wiki.avro.pro/books/kompetencii/page/bim-rabota-v-navisworks
Ссылки	
Bird Tools - Free NavisExport	https://apps.autodesk.com/RVT/en/Detail/Index?id=9181996252534034142&appLang=en&os=Win64
FREE NAVISEXPORT	https://www.birdtools-developers.com/navisworksexporter.html

FREE NAVISEXPORT

Free NavisExport - Batch Mode

List Of Revit Files To Be Exported

☐ Open Last Viewed Worksets
(Uncheck For All)

BIM 360/ACC (APS)

Destination

☒ Convert Element Properties ☐ Export Links ☒ Export Room As Attribute ☐ Find Missing Materials

☒ Divide File Into Levels ☒ Export Parts ☐ Export Room Geometry ☒ Export All Parameters
(Uncheck For None)

☒ Export Element Ids ☐ Export Internal
Coordinates (Uncheck For
Shared Coordinates) ☐ Export URLs ☐ Export Element Parameters
(Uncheck For None)

☐ Export Linked CAD
(Revit 2020+) ☐ Convert Lights (Revit
2020+) Faceting Factor (Revit 2020+)

☒ Export Entire Model ☐ Export 3D Views - Titles Contain:
(Leave Blank For All 3D Views) (Case Sensitive)

Naming Convention

Prefix - ☒ Model Name - ☐ View Name Suffix

Navisworks Batch Utility: автоматическая сборка

Выполняет пакетную выгрузку NWC+NWD

<https://www.youtube.com/embed/uO3tQRDzu68?si=w6ngfgl3YYWgY3ul>

Версия #7

Создано 10 апреля 2024 12:50:46

Георгий Новак обновил 11 октября 2024 11:56:26