

Batch Export NWC

Связи	
BIM_Работа в Navisworks	https://wiki.avro.pro/books/kompetencii/page/bim-rabota-v-navisworks
Ссылки	
Bird Tools - Free NavisExport	https://apps.autodesk.com/RVT/en/Detail/Index?id=9181996252534034142&appLang=en&os=Win64
FREE NAVISEXPORT	https://www.birdtools-developers.com/navisworksexporter.html

FREE NAVISEXPORT

Free NavisExport - Batch Mode

List Of Revit Files To Be Exported

☐ Open Last Viewed Worksets (Uncheck For All) BIM 360/ACC (APS) Browse

Destination H:_CDE\VINOGRADOV_PRAYD\02_AI\NWC\99_APXIB\240410 Browse

☒ Convert Element Properties
 ☐ Export Links
 ☒ Export Room As Attribute
 ☐ Find Missing Materials

☒ Divide File Into Levels
 ☒ Export Parts
 ☐ Export Room Geometry
 ☒ Export All Parameters (Uncheck For None)

☒ Export Element Ids
 ☐ Export Internal Coordinates (Uncheck For Shared Coordinates)
 ☐ Export URLs
 ☐ Export Element Parameters (Uncheck For None)

☐ Export Linked CAD (Revit 2020+)
 ☐ Convert Lights (Revit 2020+)
 Faceting Factor (Revit 2020+) 1

☒ Export Entire Model
 ☐ Export 3D Views - Titles Contain: (Leave Blank For All 3D Views) NAVISWORKS (Case Sensitive)

Naming Convention

Prefix - ☒ Model Name - ☐ View Name Suffix

Help
Proceed
Cancel

Navisworks Batch Utility: автоматическая сборка

Выполняет пакетную выгрузку NWC+NWD

<https://www.youtube.com/embed/uO3tQRDzu68?si=w6ngfgl3YYWgY3ul>

Версия #7

Создано 10 апреля 2024 12:50:46

Георгий Новак обновил 29 мая 2025 09:12:04