


# Секущий диапазон


Ссылки	
How to set the View Range in Revit	<a href="https://www.autodesk.com/support/technical/article/caas/sfdcarticles/sfdcarticles/Revit-Understanding-how-to-set-proper-View-Range.html">https://www.autodesk.com/support/technical/article/caas/sfdcarticles/sfdcarticles/Revit-Understanding-how-to-set-proper-View-Range.html</a>
How to Use View Range in Revit	<a href="https://www.bimpure.com/blog/how-to-use-view-range-in-revit">https://www.bimpure.com/blog/how-to-use-view-range-in-revit</a>
Revit Basics Tutorial - How To Use View Range	<a href="https://www.youtube.com/watch?v=1Sfz7GEIszl">https://www.youtube.com/watch?v=1Sfz7GEIszl</a>

## Логика



## Настройка

### План пола



View Depth  
Level: Associated Level (LEVEL 1) ▾ Offset: 0.0


## План потолка



Ceiling Plan

Top: Associated Level (FIRST FL) ▾ Offset: 3500.0

Cut plane: Associated Level (FIRST FL) ▾ Offset: 2000.0



Версия #3

Георгий Новак создал 22 января 2025 01:32:41

Георгий Новак обновил 20 марта 2025 15:31:28